



VHM-P (non-locking) and VHM-PL (locking) Variable Height Arm Operation Guide





VHM-P (non-locking)



VHM-PL (locking)



Safety Label Locations (VHM-P Series Arms)



Refer to Installation Guide for additional information.



Remove the Device only when the Arm is at the highest position.



Do not remove device when arm is in a lowered position.





Potential pinch point that may cause personal injury.



Maximum weight for mounting plate with tilt function.

Counter Balance Load Range:
 25 - 45 lbs / 11.3 - 20.4 kg
 or
 15 - 30 lbs / 6.8 - 13.6 kg

Safety Label Locations (VHM-PL Series Arms)



Refer to Installation Guide for additional information.





Potential pinch point that may cause personal injury.




Maximum weight for mounting plate with tilt function.

Counter Balance Load Range:
 25 - 45 lbs / 11.3 - 20.4 kg
 or
 15 - 30 lbs / 6.8 - 13.6 kg

VHM-P (non-locking only)




VHM-P (non-locking)




VHM-PL (locking)


VHM-P (non-locking)




VHM-PL (locking)



Tilt



Swivel



Pivot

